



# FIREGEAR<sup>®</sup>


by **earthcore<sup>®</sup>**

## "PRO SERIES"

**DO NOT DISCARD. THIS MANUAL  
HAS IMPORTANT OPERATING AND  
MAINTENANCE INSTRUCTIONS.  
LEAVE WITH THE HOMEOWNER.**

**MODEL:**

**SERIAL #:**



Brass T-Burner

| Models              | Models              | Description                     |
|---------------------|---------------------|---------------------------------|
| N= Natural Gas      | P= Propane          |                                 |
| LOF-3006PS24TTPSI-N | LOF-3006PS24TTPSI-P | 30" x 6" Pan & 24" Pro T-Burner |
| LOF-4206PS38TTPSI-N | LOF-4206PS38TTPSI-P | 42" x 6" Pan & 38" Pro T-Burner |
| LOF-4806PS44TTPSI-N | LOF-4806PS44TTPSI-P | 48" x 6" Pan & 44" Pro T-Burner |
| LOF-6006PS56TTPSI-N | LOF-6006PS56TTPSI-P | 60" x 6" Pan & 56" Pro T-Burner |
| LOF-7206PS68TTPSI-N | LOF-7206PS68TTPSI-P | 72" x 6" Pan & 68" Pro T-Burner |

## Drop-In Linear Fire Pits with Thermocouple Piloted Safety Ignition (TPSI) & Pro Brass T-Burner

### Installation and Operating Instructions

**IF YOU CANNOT READ OR UNDERSTAND THESE INSTALLATION INSTRUCTIONS  
DO NOT ATTEMPT TO INSTALL OR OPERATE THIS APPLIANCE**

These fire pits are manufactured from the factory as Natural or Propane Gas.  
Ensure you order the proper gas type before installing.

### **INSTALLATION PRECAUTION:**

This fire pit requires a minimum 18-square inches (per side) of cross ventilation.  
Failure to provide proper ventilation can void the warranty.



**Warning:** For Outdoor Use Only



We recommend that our gas  
hearth products be installed  
and serviced by profes-  
sionals who are certified in  
the U.S. by the National  
Fireplace Institute<sup>®</sup> (NFI) as  
NFI Gas Specialists.



## DANGER



## CARBON MONOXIDE HAZARD

This appliance can produce carbon monoxide which has no odor.

Using it in an enclosed area can kill you.

Never use this appliance in an enclosed space such as a camper, tent, car or home.



## DANGER

If you smell gas:

1. Shut off gas to the appliance
2. Extinguish any open flame.
3. If odor continues, keep away from the appliance and immediately call your gas supplier or fire department.



## WARNING

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or other appliances.

Any LP cylinder not connected for use shall not be stored in the vicinity of this or other appliances.

## WARNING

Do not leave unattended during use.  
Do not use for cooking.  
Follow all gas leak procedures in this manual prior to operation.



## WARNING

Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Read the installation, operating and maintenance instructions thoroughly before installing or servicing this equipment.

## WARNING

If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

## FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or other appliances.



Fuels used in gas fired appliances, and the products of combustion such as fuels, contain chemicals known to cause cancer, birth defects and/or other reproductive harm.  
This warning is issued pursuant to the California Health & Safety Code Sec. 25249.1



## CALIFORNIA PROPOSITION 65



### WARNING

This product is designed to operate with one of the following fuel sources: Liquid Propane or Natural Gas. The fuel used to operate this product, and the products of combustion of such fuel, can expose you to chemicals including Benzene which is known to the State of California to cause cancer, birth defects and other reproductive harm and Carbon Monoxide which is known to the State of California to cause birth defects or other reproductive harm.

(For more information go to: [www.p65Warnings.ca.gov](http://www.p65Warnings.ca.gov).)

**NOTE:** An exterior lid/cover is not required but highly recommended when the fire pit is not in use. Even though fire pits are designed for outdoors they are not impervious to all weather conditions if not protected. See the accessory page for information and sizes.

### TABLE OF CONTENTS

|                                                  |     |
|--------------------------------------------------|-----|
| <b>Specifications</b>                            | 4   |
| <b>Preparation for Non-Combustible Structure</b> | 5   |
| Hard Piping to Fire Pit                          | 5   |
| Cross Ventilation Requirements                   | 6   |
| High Elevation                                   | 6   |
| <b>Installation into an Approved Enclosure</b>   | 6   |
| Gas Pipe Sizing Chart                            | 7   |
| <b>Removing Parts from Carton</b>                | 8   |
| Preparing Burner Pan for Installation            | 9   |
| Typical Installation Drawings                    | 8-9 |
| <b>Operation</b>                                 | 10  |
| Lighting Instructions                            | 10  |
| <b>TPSI Replacement Parts</b>                    | 11  |
| <b>TPSI Replacement Parts List</b>               | 12  |
| <b>Fire Pit Maintenance/Trouble Shooting</b>     | 13  |
| <b>Optional Accessories</b>                      | 14  |

**Congratulations!** You have just purchased a Firegear Outdoors “Pro Series” T-Burner. These are Brass Burners that come in six sizes, 24”, 34”, 42” 56” and 68” models. Each model incorporates individual injectors that eliminates the need for a main burner orifice. The 24” model incorporates 23 injectors where up to the 68” model has 67 injectors. All models vary with the quantity of injectors.



All media (i.e. lava rock, lava stones, lava boulders and fire glass) has the potential of thermal spalling. This is a process that may occur when media is wet and moisture gets trapped inside of the material due to rapid temperature differences. When this happens the media has the potential to crack or “pop” outside the fireplace.

**WE HIGHLY RECOMMEND COVERING ALL FIRE FEATURES WHEN NOT IN USE**

The use of a cover can lessen the impact of thermal spalling; however, heavy rains, high humidity and the presence of moisture may still cause the media to pop.

**ALWAYS USE CAUTION WHEN USING THE FIRE FEATURE**

Extra caution should be taken when lighting a fireplace when heavy rains, high humidity and moisture are present. Light the fireplace; leave the area allowing any moisture in the media to dissipate. We strongly recommend that during this drying out time that you monitor the fire feature from a distance. This drying out period should be no less than 30 minutes. Continue monitoring the flame from distance to ensure that all popping has ceased before fully enjoying the fire.



## SPECIFICATIONS

| MODELS<br>N = Natural<br>P = Propane       | PAN OUTSIDE<br>DIMENSIONS    | PAN INSIDE<br>DIMENSIONS   | MIN.<br>OPENING            | BURNER<br>LENGTH | GROUND<br>LEVEL | SIDE<br>WALL   | COMBUSTIBLE<br>CEILING | COMBUSTIBLE<br>FLOOR |
|--------------------------------------------|------------------------------|----------------------------|----------------------------|------------------|-----------------|----------------|------------------------|----------------------|
| LOF-3006PS24TTPSI-N<br>LOF-3006PS24TTPSI-P | 32½" x 8½"<br>(826 x 216mm)  | 30" x 6"<br>(762 x 152mm)  | 31" x 7"<br>(787 X 178mm)  | 24"<br>(609 mm)  | 8"<br>(203mm)   | 36"<br>(914mm) | 96"<br>(2438mm)        | 18"<br>(457mm)       |
| LOF-4206PS38TTPSI-N<br>LOF-4206PS38TTPSI-P | 44½" x 8½"<br>(1130 x 216mm) | 42" x 6"<br>(1067 x 152mm) | 42" x 7"<br>(1092 X 178mm) | 38"<br>(864mm)   | 8"<br>(203mm)   | 36"<br>(914mm) | 96"<br>(2438mm)        | 18"<br>(457mm)       |
| LOF-4806PS42TTPSI-N<br>LOF-4806PS42TTPSI-P | 50½" x 8½"<br>(1283 x 216mm) | 48" x 6"<br>(1219 X 152mm) | 49" x 7"<br>(1245 X 178mm) | 44"<br>(1118mm)  | 8"<br>(203mm)   | 36"<br>(914mm) | 96"<br>(2438mm)        | 18"<br>(457mm)       |
| LOF-6006PS56TTPSI-N<br>LOF-6006PS56TTPSI-P | 62½" x 8½"<br>(1588 x 216mm) | 60" x 6"<br>(1524 x 152mm) | 59" x 7"<br>(1499 X 178mm) | 56"<br>(1422mm)  | 8"<br>(203mm)   | 36"<br>(914mm) | 120"<br>(3048mm)       | 18"<br>(457mm)       |
| LOF-7206PS68TTPSI-N<br>LOF-7206PS68TTPSI-P | 74½" x 8½"<br>(1892 x 216mm) | 72" x 6"<br>(1828 x 152mm) | 73" x 7"<br>(1854 X 178mm) | 68"<br>(1727mm)  | 8"<br>(203mm)   | 36"<br>(914mm) | 120"<br>(3048mm)       | 18"<br>(457mm)       |

**Table 1** Fire Pit Dimensions




**Fig. 1** T-style burner pan specifications.

**Fig. 2** Clearance to Combustibles for models.  
(Not to be used in an enclosed space)

| Pressure     | NG                 | LP                  |
|--------------|--------------------|---------------------|
| Min. Inlet   | 3.5" WC (0.87 kPa) | 8.0" WC (1.99kPa)   |
| Max. Inlet   | 10.5" WC (2.61kPa) | 13.0" WC (3.23 kPa) |
| Normal Inlet | 7.0" WC (1.74 kPa) | 11.0" WC (2.73 kPa) |

**Table 2** Gas Pressures

| Models:<br>Natural Gas | #<br>Jets | NG Injector<br>Size | BTU<br>Ratings | Models:<br>Propane Gas | NG Injector<br>Size | LP Injector<br>Size |
|------------------------|-----------|---------------------|----------------|------------------------|---------------------|---------------------|
| LOF-3006PS24TTPSI-N    | 23        | #72 (0.025)         | 50K (23.44kW)  | LOF-3006PS24TTPSI-P    | #78 (0.016)         | 60K (17.58kW)       |
| LOF-4206PS38TTPSI-N    | 37        | #72 (0.025)         | 90K (27.84kW)  | LOF-4206PS38TTPSI-P    | #78 (0.016)         | 95K (27.84kW)       |
| LOF-4806PS44TTPSI-N    | 43        | #72 (0.025)         | 100K (36.16kW) | LOF-4806PS44TTPSI-P    | #78 (0.016)         | 110K (32.23kW)      |
| LOF-6006PS56TTPSI-N    | 55        | #72 (0.025)         | 135K (46.89kW) | LOF-6006PS56TTPSI-P    | #78 (0.016)         | 140K (41.02kW)      |
| LOF-7206PS68TTPSI-N    | 67        | #72 (0.025)         | 140K (52.75kW) | LOF-7206PS68TTPSI-P    | #78 (0.016)         | 170K (49.82kW)      |

**Table 3** T-burner specifications.

**Disclaimer:** BTU listings are based on 7.0"WC for Natural Gas and 11.0"WC for Liquid Propane (LP) at the burner orifice. Flex line size and proper gas pipe sizing will also affect BTU's. As a result your BTU's may vary slightly from Table 2 specifications.



## PREPARING A NON-COMBUSTIBLE STRUCTURE

**Description:** These fire pits are designed to be installed into a non-combustible enclosure. They are a “drop-in pan” style system to make installation quick and convenient. Media (not supplied) is required inside the burner pan for operation (See page 9).

**WARNING:** Proper clearances from combustible materials must be maintained from all sides, top and bottom of this appliance. Use the specifications listed on pages 4 for proper clearance to combustibles.

Firegear Outdoors fire pits are constructed and tested to follow the rigid ANSI standards for gas appliances and manufactured safely providing dependable and certified products. If these fire pits are not installed according to the installation manual (i.e. not providing ventilation, not providing proper drainage, installing fire pits below grade or modifying the existing products from a normal installation) Firegear Outdoors cannot be responsible if the product does not operate as designed.

Modifying the fire pit directly out of the carton will void the warranty and nullify the product listing it was certified for. Before you consider creating your own custom design with a certified product ensure you contact Firegear to consult the installation before proceeding. If you move forward and modify a product without consulting, Firegear cannot be responsible if the product does not operate as designed.

The fire pit can be installed on a flat, stable surface, away from any combustible materials. Install fire pit on any level, outdoor non-combustible, flat stable surface or a combustible floor according to the clearances specified in this manual.

**NOTE:** Do not place fire pit directly on grass, dirt, or rocks this may prevent proper ventilation. **Ensure proper water drainage is also incorporated into the fire pit enclosure.**

### **HARD PIPING TO FIRE PIT WITHOUT GAS PROXIMITY**

**NOTE:** Refer to the NFPA54 (National Fuel Gas Code) for proper pipe sizing. See gas line sizing chart on page 7 as a reference.

1. Turn **OFF** gas supply system. **NOTE:** All gas connections (except for brass to brass) require the following. Clean pipe threads using either a wire brush or steel wool. Apply pipe sealant to the fittings before making any connection.

**BE CAREFUL!** Ensure all gas connections are snug, but do not over tighten!

2. Extend the gas supply system using minimum of ¾” black iron pipe or an approved flexible gas line from existing house supply. This can be accomplished by teeing off or tapping into a gas line connection. Install necessary pipe for the distance required and then install a manual shut-off valve at the exterior house wall. If pipe is to pass through a foundation or house wall, make sure to re-seal the area around the pipe with weather sealant.

3. The primary gas shut-off (not supplied) will require a ½” male flared fitting to enable connection of the stainless steel flex gas line supplied with the fire pit (see Fig. 7 page 9).

### **IMPORTANT**

Installation of Natural or LP gas should be done by a qualified installer, service agency or gas supplier.

This appliance must be isolated from the gas supply piping system by closing its manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than ½” psig (3.5kPa)

**Injectors/Jets** - Fire features using a Pro Series brass burner incorporates individual injectors/jets on each burner leg. All injectors are protected by an injector cover that is provided with each burner. The injector hole size is measured by using a numbered drill bit. An injector/jet limits the amount of gas flow to the burner to ensure the flame is a safe and reasonable height to not pose a risk to people or property. **Note:** The Pro Series brass burners **DO NOT USE** a primary main burner orifice like a standard stainless steel burner. A steel nipple is installed in place of the primary burner orifice. Each injector is installed at an angle inside each burner leg to maximize flame appearance.



**ALL PAN OR FLAT DISCS MUST BE REMOVABLE FOR SERVICE** Pans or Discs CANNOT be installed in a manner to prevent them from being removed for service. Top coping material or top cap of fire pit MUST NOT overlap onto the pan or disc surface without easily being removed. Pan lip of disc edge must be unobstructed so it can be lifted out of the fire pit for servicing. We highly recommend the use of a flex frame kit for all installations.



## PREPARING A NON-COMBUSTIBLE STRUCTURE

### VENTILATION FOR NON-COMBUSTIBLE ENCLOSURE

Fire pits are subjected to many outdoor elements such as rain, snow, wind, heat or cold. **A minimum of 18 square inches (two opposite sides) of cross ventilation is required to keep the components in good working order.** Use Fig. 3 as guide to assist to incorporate proper ventilation.

#### Examples of Cross Ventilation

2- Firegear 6 x12 vents  
(Model # VENT-KIT-6X12)




Fig. 3 Cross ventilation example

## INSTALLATION OF FIRE PIT INTO AN APPROVED ENCLOSURE

### REQUIREMENTS

1. Only non-combustible materials should come in direct contact with any part of the fire pit. Underneath area should be non-combustible or a flat level combustible surface according to the clearances specified in this manual.
2. Refer to the NFPA54 (National Fuel Gas Code) for proper pipe sizing. Determine the size of the fire pit you are preparing to install (Refer to page 7).
3. You must provide a rectangular opening cutout to place the fire pit into the non-combustible enclosure. Refer to Table 1, dimension A.
4. Follow the local code requirements for the gas type being used. This fire pit should be installed in accordance with local codes and ordinances or in the absence of local codes, with the latest National Fuel Gas Code, ANSI Z223.1 NFPA54 or CSA B149.1, Natural and Propane Installation Code in Canada.
5. Fire pits create high temperatures, it is very important to have any combustibles at a safe distance.
6. DO NOT place an LP tank inside any fire pit enclosure. Locate all Propane (LP) tanks outside the enclosure.
7. **CAUTION: A minimum of 18 square inches of cross ventilation (opposite sides) is required to keep the enclosure dry. See Fig. 3.**
8. These products are **designed for outdoor use only**. Not approved for any indoor use.
9. This fire pit is designed to have AMD Direct, Inc lava rock or glass media completely covering the burner, so that the burner is not visible. Do not cover more than 1" above the top of burner. Ensure the injectors are not blocked by any media. Use lava rock a minimum of 1" diameter as a base to fill the burner pan. DO NOT USE STONE OR RIVER ROCK.
10. Gas lines and fittings must be installed into the non-combustible structure. All gas connections must be leak tested before installation of the fire pit. Soapy water leak detection is required before regular use of the fire pit.
11. Do not use media that will absorb moisture over time and will not release this moisture quickly. Moisture can boil in this material and can rapidly break apart and cause damage or personal injury. See Caution on bottom of page 3.
12. Never leave any combustible material on top of the fire pit. This could cause unsafe operation of this system and damage to the component that will not be covered under our warranty.
13. Ensure proper water drainage is also incorporated into the fire pit enclosure.



# GAS PIPE SIZING CHART

## NATURAL GAS : PIPE SIZING CHART

| Length of Pipe in Feet | 1/2" | 3/4" | 1"  | 1 - 1/4" | 1 - 1/2" | 2"   | 2 - 2 1/2" | 3"   | 4"   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------|------|------|-----|----------|----------|------|------------|------|------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 10                     | 108  | 230  | 387 | 793      | 1237     | 2259 | 3640       | 6434 | -    | <ul style="list-style-type: none"> <li>Natural Gas (NG) flow is given in thousands of BTU/hr. = 1 cubic foot of NG gas - 1000 BTU</li> <li>Nominal pressure at the burner for Natural Gas is 3.5" of water column. (Typical machine supply 5"-7")</li> <li>Pipe length must include additional length for all fittings. Add approximately 5 feet of pipe per fitting.</li> <li>Natural Gas Example: A machine with a burner that requires 440,000 BTU would need a 1 - 1/4" pipe for a 20" long run.</li> </ul> |
| 20                     | 75   | 160  | 280 | 569      | 877      | 1610 | 2613       | 5236 | 9521 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 30                     | 61   | 129  | 224 | 471      | 719      | 1335 | 2165       | 4107 | 7859 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 40                     | 52   | 110  | 196 | 401      | 635      | 1143 | 1867       | 3258 | 6795 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 50                     | 46   | 98   | 177 | 364      | 560      | 1041 | 1680       | 2936 | 6142 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 60                     | 42   | 89   | 159 | 336      | 513      | 957  | 1559       | 2684 | 5647 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 70                     | 38   | 82   | 149 | 317      | 476      | 896  | 1447       | 2492 | 5250 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 80                     | 36   | 76   | 140 | 239      | 443      | 840  | 1353       | 2315 | 4900 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 90                     | 33   | 71   | 133 | 275      | 420      | 793  | 1288       | 2203 | 4667 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 100                    | 32   | 68   | 126 | 266      | 411      | 775  | 1246       | 2128 | 4518 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 125                    | 28   | 60   | 117 | 243      | 369      | 700  | 1143       | 1904 | 4065 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 150                    | 25   | 54   | 105 | 215      | 327      | 625  | 1008       | 1689 | 3645 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 175                    | 23   | 50   | 93  | 196      | 303      | 583  | 993        | 1554 | 3370 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 200                    | 22   | 47   | 84  | 182      | 280      | 541  | 877        | 1437 | 3160 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |
| 300                    | 17   | 37   | 70  | 145      | 224      | 439  | 686        | 1139 | 2539 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 |

## LIQUID PROPANE : PIPE SIZING CHART

| Length of Pipe in Feet | 1/2" | 3/4" | 1"   | 1 - 1/4" | 1 - 1/2" | 2"   | 2 - 2 1/2" | 3"    | 4"    |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
|------------------------|------|------|------|----------|----------|------|------------|-------|-------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 10                     | 275  | 567  | 1071 | 2205     | 3307     | 6221 | 10140      | 17990 | 35710 | <ul style="list-style-type: none"> <li>Liquid Propane (LP) Gas flow is given in thousands of BTU/hr. = 1 cubic foot of LP gas - 2500 BTU.</li> <li>This chart refers to low pressure LP, after regulation, Standard nominal pressure at the burner for Liquid Propane Gas is 11" of water column.</li> <li>Pipe length must include additional length for all fittings. Add approximately 5 feet of pipe per fitting.</li> <li>LP Example: A machine with a burner that requires 440,000 BTU would need a 1" pipe for a 20' long run.</li> </ul> |
| 20                     | 189  | 393  | 732  | 1496     | 2299     | 4331 | 7046       | 12510 | 25520 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 30                     | 152  | 315  | 590  | 1212     | 1858     | 3465 | 5695       | 10110 | 20620 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 40                     | 129  | 267  | 504  | 1039     | 1559     | 2992 | 4778       | 8481  | 17300 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 50                     | 114  | 237  | 448  | 913      | 1417     | 2646 | 4343       | 7708  | 15730 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 60                     | 103  | 217  | 409  | 834      | 1275     | 2394 | 3908       | 6936  | 14150 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 70                     | 89   | 185  | 346  | 724      | 1086     | 2047 | 3329       | 5908  | 12050 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 80                     | 78   | 162  | 307  | 630      | 976      | 1811 | 2991       | 5309  | 10830 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 90                     | 69   | 146  | 275  | 567      | 866      | 1606 | 2654       | 4711  | 9613  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 100                    | 63   | 132  | 252  | 511      | 787      | 1496 | 2412       | 4281  | 8736  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 125                    | 54   | 112  | 209  | 439      | 665      | 1282 | 2083       | 3618  | 7382  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 150                    | 48   | 100  | 185  | 390      | 590      | 1138 | 1808       | 3210  | 6549  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 175                    | 43   | 90   | 168  | 353      | 534      | 1030 | 1637       | 2905  | 5927  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 200                    | 40   | 83   | 155  | 325      | 491      | 947  | 1505       | 2671  | 5450  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |
| 300                    | 37   | 77   | 144  | 303      | 458      | 887  | 1404       | 2492  | 5084  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |

NOTE: The sizing charts above list the specific pipe sizes required for the amount of BTU's for a new gas line installations. If you are using an existing gas line you must take into consideration the existing gas line capacities to ensure you will have proper pressure. **This chart is for reference only, we recommend you consult with a Licensed Plumber/Gas Fitter or NFPA54 (National Fuel Gas Code - current edition) for more details.**

**Table 4** Gas pipe sizing.



## REMOVING PARTS FROM CARTON




**Fig. 4** Removing contents from carton.

The fire pit comes partially assembled from the factory. The pilot tubing and thermocouple leads are 48" in total length, therefore, when mounting the Gas Valve/Piezo mounting plate, ensure the mounting plate is close enough to make all connections.

Open carton and remove contents. Inspect for any damage or missing parts.

The hardware bag includes mounting plate screws, orifice, Piezo wires and flex connector to complete the installation.

Carefully install the fire pit into the prepared enclosure, connect the gas line and wire according to the figure drawings in this manual.




**Fig. 5** Installing gas line to Pro Burner.

### **INSTALLING NIPPLE INTO BURNER**

#### **Before the fire pit is installed:**

Install a 2" nipple and flared fitting into the bottom of the burner. Ensure the nipple has gas rated Teflon tape wrapped around the threads. Thread the nipple into the burner in a clockwise manner. Secure into position. See Fig. 5.

### **CONTROL PANEL MOUNTING PLATE**

The control panel mounting plate is pre-assembled at the factory with the gas valve and Piezo ignitor. On the back of this manual is a template for use to cut an opening for the mounting plate. Once you have determined the location of control panel mounting plate install the gas connections and Piezo wires as shown in Fig. 6 and secure all connections.




**Fig. 6** Installing control panel into PAVER-CP-MT mounting plate.



## PREPARING BURNERPAN FOR INSTALLATION




Fig. 7 Typical installation.



## FINAL PREPARATION

### INJECTOR HOOD/RAIN SHIELD INSTALLATION

Install the hood/rain shields over top of each injector of the pro brass burner by sliding it into position. Use the bead in the lower section of the hood, and align it with the groove in the injector, until it snaps into place. See Fig. 8. Rotate the hood to ensure it is protecting the injector opening from the elements (i.e. rain, dirt or media). See Fig. 9 for proper alignment. **Note:** If there is no detent in the injector, ensure the hood is  $\frac{1}{2}$ " from the base of the injector to the bottom edge of the hood.




Fig. 8 Installing injector hoods.




Fig. 9 Correct placement of injector hoods.

### INSTALLATION OF MEDIA INTO BURNER PAN

Install lava rock into the burner pan. Ensure the lava rock is a minimum of 1-inch diameter for proper operation.

**Note:** Do not pour Lava Rock directly from bag. It should be placed naturally and NOT packed in tight. Loose fitting is important to ensure robust flames. Placing the lava rock in the pan by hand, ensures no excessive dust from bag lays in the bottom of pan and potentially plugs the burner port holes or the pan weep holes. **DO NOT BLOCK INJECTORS WITH MEDIA.**

**IF USING AMD DIRECT, INC GL GLASS OR GLR REFLECTIVE GLASS, ENSURE THE MEDIA DOES NOT BLOCK THE INJECTOR HOLES.**

**IMPORTANT: DO NOT PLACE ROCK OVER TOP OR UNDER THE PILOT SCREEN COVER.** The screen must be free of any debris to ensure proper lighting of burner and good flame sense (See Fig. 11).

Cover the burner completely with media but do not make the depth greater than 1-inch over-top of the burner port holes.

Do **NOT** cover the top of mesh pilot hood with any rock or glass. It must be free of any debris to operate properly.




Fig. 10 Media placement around pilot hood.

Acceptable media to be placed over top of the burner:

**Lava Rock** Min. 1" - 2" size  
FG-LAVA-10 (10 LB)  
FG-LAVA-40 (1 CUBIC FOOT)

**GL Glass** Min.  $\frac{1}{2}$ " -  $\frac{3}{4}$ " size  
Various colors are available  
See Product catalog for details  
*Sold in 10LB jugs*

**GRL Reflective Glass**  
Min.  $\frac{1}{2}$ " -  $\frac{3}{4}$ " size  
Various colors are available  
See Product catalog for details  
*Sold in 10LB jugs*



## OPERATION

**CAUTION:** Children and adults should be alerted to the hazards on high surface temperatures and should stay away to avoid burns or clothing ignition. Young children should be carefully supervised when they are in the area of the appliance.

**WARNING:** Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of control system and any gas control, which has been under water.

### SAFETY WARNINGS

1. Never leave the fire pit unattended during operation.
2. Clothing or other flammable materials should not be placed on or near the appliance.
3. Any guard or other protective device removed for servicing the appliance must be replaced prior to operating the appliance.
4. Installation and repair should be done by a qualified service person. The appliance should be inspected before use and at least annually by a qualified service person. More frequent cleaning may be required as necessary. It is imperative the control compartment, burners and circulating air passageways of the appliance be kept clean.
5. Inspect the fuel supply connection before each use of the appliance.
6. Temporary storage of this appliance indoors is permissible only if it has been disconnected from its fuel supply (Natural or L.P. gas line).

### WARNING

1. This appliance is hot when operated and can cause severe burns if contacted.
2. Do not burn any solid fuels in this appliance.

### **READ ALL LIGHTING INSTRUCTIONS BEFORE ATTEMPTING TO LIGHT FIRE PIT**

**CAUTION:** ENSURE YOU HAVE LEAK TESTED THE FIRE PIT BEFORE OPERATING.

**WARNING: Do not stand over fire pit during ignition or operation due to high surface temperatures.**

## LIGHTING INSTRUCTIONS

### **TURNING ON FIRE PIT**

1. Depress and hold the red Piezo button and ensure sparking is occurring inside the pilot hood. An audible sparking sound can be heard.
2. While holding the Piezo button, slightly depress the control knob inward and rotate counter clockwise to the PILOT position. Depress and hold control knob inward for at least 30 to 60 seconds; to light the PILOT.
3. Once the pilot lights, release the Piezo button and turn control knob counter clockwise to the ON position. If pilot does not stay lit, release the control knob, turn the control knob clockwise to turn OFF and wait 5 minutes before trying again. Turn gas supply OFF to check ignitor spacing and Piezo battery if no sparking occurs.
4. Repeat steps 1-4 to try again.

### **TURNING OFF FIRE PIT**

1. Slightly depress the control knob inward and rotate the knob clockwise to OFF position. Fire pit will turn OFF.
2. After cooling off install cover (if applicable).















**Fig. 11** Control panel with gas valve knob and Piezo.



## TPSI REPLACEMENT PARTS



Drawings not to scale.



## TPSI REPLACEMENT PARTS LIST

| Item | Description                                                             | Qty. | Part #           |
|------|-------------------------------------------------------------------------|------|------------------|
| 1    | 30" x 6" Linear Drop-In Pan Only - used with 24" burner                 | 1    | 78033            |
| 1    | 42" x 6" Linear Drop-In Pan Only - used with 38" burner                 | 1    | 78230            |
| 1    | 48" x 6" Linear Drop-In Pan Only - used with 44" burner                 | 1    | 78035            |
| 1    | 60" x 6" Linear Drop-In Pan Only - used with 56" burner                 | 1    | 78036            |
| 1    | 72" x 6" Linear Drop-In Pan Only - used with 68" burner                 | 1    | 78037            |
| 2    | 24" T-Burner only - <b>Natural Gas</b> - used with 30" x 6" burner pan  | 1    | 10809            |
| 2    | 38" T-Burner only - <b>Natural Gas</b> -used with 36" x 6"-burner pan   | 1    | 10810            |
| 2    | 44" T-Burner only - <b>Natural Gas</b> -used with 48" x 6" burner pan   | 1    | 10811            |
| 2    | 56" T-Burner only - <b>Natural Gas</b> -used with 60" x 6" burner pan   | 1    | 10812            |
| 2    | 68" T-Burner only - <b>Natural Gas</b> -used with 72" x 6" burner pan   | 1    | 10813            |
| 2    | 24" T-Burner Only - <b>Propane Gas</b> - used with 30" x 6" Drop In Pan | 1    | 10818            |
| 2    | 38" T-Burner Only - <b>Propane Gas</b> - used with 36" x 6" Drop In Pan | 1    | 10819            |
| 2    | 44" T-Burner Only - <b>Propane Gas</b> - used with 48" x 6" Drop In Pan | 1    | 10820            |
| 2    | 56" T-Burner Only - <b>Propane Gas</b> - used with 60" x 6" Drop In Pan | 1    | 10821            |
| 2    | 68" T-Burner Only - <b>Propane Gas</b> - used with 72" x 6" Drop In Pan | 1    | 10822            |
| 3    | Brass Burner Support & Hardware Bag                                     | 1    | 10850            |
| 4    | ½" Flex Gas Line (46-inch Length)                                       | 1    | T-200-9898-46    |
| 5    | Copreci High Capacity Gas Valve                                         | 1    | 68001599         |
| 6    | Lock Nut, M15 x 1 for TPSI Gas Valve                                    | 1    | 08032504         |
| 7    | Gas Valve Control Knob for TPSI Valve                                   | 1    | CN-ALHC          |
| 8    | Complete Natural Gas Pilot Assembly with 48" leads                      | 1    | PSE-NA495        |
| 9    | Complete Propane Gas Pilot Assembly with 48" leads                      | 1    | PSE-LP495        |
| 10   | TPSI Face Plate                                                         | 1    | 78188            |
| 11   | ½" OD Flare to 3/8" MIP Fitting                                         | 1    | U1-8C-S          |
| 12   | ½" NPT Female to ½" Male Flare Fitting                                  | 1    | U3-8D-S          |
| 13   | ½" Flare to ½" MIP 90° elbow                                            | 1    | 49-88            |
| 14   | LP Regulator with 32" Hose - <b>NOT FOR USE WITH NATURAL GAS</b>        | 1    | FG-32LPHRK       |
| 15   | ¾" MIP x 2" Stainless Steel Nipple (not shown)                          | 1    | 10858            |
| 16   | ½" Flare to ¾" FIP Fitting (used with all kits) (not shown)             | 1    | 46-86            |
| 17   | Manual Spark Ignitor Module (not shown)                                 | 1    | 3042-RB          |
| 18   | Spark Ignitor for 3042-RB (not shown)                                   | 1    | 3042-RB -IGNITOR |
| 19   | Plastic Nut for 3042-RB (not shown)                                     | 1    | 3042-RB-NUT      |
| 20   | 25" Piezo Extension wire - See page 16 (not shown)                      | 1    | PIEZO25WH        |
| 21   | 48" Piezo Extension wire - See page 16 (not shown)                      | 1    | PIEZO48WH        |
| 22   | Ground tab for Piezo ignition (not shown)                               | 1    | GROUNDTAB        |



## FIRE PIT MAINTENANCE

1. The fire pit should be inspected and cleaned before initial use, at least annually, by a qualified field service person.
2. Any component that is found faulty must be replaced with an approved component.
3. Any tampering or modifying with the fire pit is dangerous and voids all warranties.
4. During winter months in cold climates and various seasons of operation the fire pit may be affected by weather conditions. It is recommended to use a ventilated cover over top of your fire pit to protect it from humid/rainy weather conditions when not in use. Heavy rains/downpours could affect the fire pit operation if not covered; if this occurs ensure you allow the fire pit time to dry out before attempting to operate. **NOTE:** If a combustible type cover is used over the fire pit when not in use be sure to remove it before operation to prevent a severe safety hazard.
5. Over time stainless steel parts can discolor when heated, usually a golden or brown hue. This discoloration is normal and does not affect the performance of the appliance.

### Brass Burner Maintenance Information:

- Dust in injector - Use compressed air from aerosol can or compressor.
- Check for bug nests or stubborn debris - replacement where necessary.

**Note:** Always use safety equipment including but not limited to SAFETY glasses or goggles when using compressed air and consider a disposable mask for particulate.

## TROUBLE SHOOTING

| <u>Symptom</u>       | <u>Remedy</u>                                                                                                                                                                                                                                                                                                                                       |
|----------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Fire pit won't light | <ol style="list-style-type: none"><li>1. Bleed gas line.</li><li>2. Ensure all gas supply lines are turned ON.</li><li>3. Ensure there is not too much media over top of burner; it can inhibit gas from flowing.</li><li>4. Check gas pressure.</li></ol>                                                                                          |
| Low flame            | <ol style="list-style-type: none"><li>1. Ensure the base media is at least 1-inch in diameter and top media is no more than 1-inch over top of burner and do not cover injectors.</li><li>2. Ensure all shut-off valves and key valve is fully open. See page 9; Fig. 7</li><li>3. Check gas pressure.</li></ol>                                    |
| Water in my fire pit | <ol style="list-style-type: none"><li>1. Excess dust/sand material from media may be blocking the weep holes to relieve water.</li><li>2. Remove all media and unplug weep holes. Clean or install new media free of dust and dirt.</li><li>3. Ensure fire pit enclosure has proper drainage for water and proper ventilation to dry out.</li></ol> |

### FOR TECHNICAL SERVICE, CALL:


Firegear Outdoors, an Earthcore Industries Brand  
1600 Riverfork Drive  
Huntington, IN 46750  
260-388-5653  
techsupport@firegearoutdoors.com

*Manual changes often occur, ensure to check the Firegear website for any recent updates and warranty information.*



## OPTIONAL ACCESSORIES

The following accessories are available from your local Firegear Outdoors dealer/distributor.  
Each accessory comes with a separate installation manual. Read each instruction thoroughly before installing.

|                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                             |                                                                                                                                                                                                                                                                                                                       |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p><u>Lids for T-Burner Fire Pits</u></p> <p><b>Models:</b><br/>LID-LOF3006; LID-LOF3606;<br/>LID-LOF4806; LID-LOF6006;<br/>LID-LOF7206</p>                                            | <p><u>Media</u></p> <p><i>Lava Stones</i> 1" to 2" size (50lbs.)<br/><b>Models:</b> FG-LS50 (Bag)</p> <p><i>Lava Rock</i> 1" to 2" size<br/><b>Models:</b> FG-LAVA-40 (Bag)<br/>FG-LAVA-10 (Bag)</p> <p>See catalog for various colors.</p> | <p><u>Glass Windshields</u></p> <p>See catalog for a windshield to fit your application.</p> <p><u>FLEXFRAME</u></p> <p>Universal brackets to support fire pit when using paver blocks or other non-combustible enclosures.</p> <p><b>Model:</b> FLEXFRAME-SS (2 piece)<br/><b>Model:</b> FLEXFRAME-SS3 (3 piece)</p> |
| <p><u>Paver Control Panels</u></p> <p>PAVER-CP-TMSI TMSI systems</p> <p><u>Vent Kits</u></p> <p>Provide 18 sq. in of ventilation per side of enclosure)</p> <p><b>Model:</b> VENT-KIT-6X12SS<br/><b>Model:</b> PAVER-VENT-4-LNTS<br/><b>Model:</b> PAVER-VENT-6-LNTS</p> | <p><u>E-STOP</u></p> <p>Mechanical gas timer valve with emergency shut-off.</p> <p><b>Model:</b> ESTOP1-0H 1hr. timer</p>                                                                                                                   | <p><u>Shut-Off Valves</u></p> <p><b>Model:</b> 01-387 3/8" OD Flare x 1/2" FIP<br/><b>Model:</b> 01-487 1/2" OD Flare x 1/2" FIP<br/><b>Model:</b> 01-266<br/>3/8" OD Flare x 3/8" OD Flare<br/><b>Model:</b> 01-288<br/>1/2" OD Flare x 1/2" OD Flare</p>                                                            |

**NOTE:** See the Firegear Outdoors catalog for other accessories also available.



Firegear Outdoors hereby warrants to the end user that products will be free from material and workmanship defects that prevent safe and correct operation of the product. The warranty commences from date of sale to the end user for the following period:

**ALL WARRANTIES WITHIN THIS DOCUMENT ONLY APPLY TO PRODUCTS MANUFACTURED AFTER | 01 / 01 / 2026**

**BURNER SYSTEMS | BURNERS | COMPONENTS | ACCESSORIES**

| <b>TYPE OF PRODUCT</b>                                   | <b>CONSUMER APPLICATIONS</b> | <b>COMMERCIAL APPLICATIONS</b> |
|----------------------------------------------------------|------------------------------|--------------------------------|
| Construction and Manufacturer Defects                    | Lifetime Warranty            | 2 Year Warranty                |
| Stainless Steel Burners and Pans                         | Lifetime Warranty            | 2 Year Warranty                |
| Pro Series Burners                                       | Lifetime Warranty            | 2 Year Warranty                |
| Gas Valve, Spark Igniter, and Pilot Assemblies           | 5 Year Warranty              | 2 Year Warranty                |
| AWS Electronic Ignition Systems (12 VAC, 24 VAC, 30 VAC) | 3 Year Warranty              | 1 Year Warranty                |
| TPSI Electronic Components                               | 5 Year Warranty              | 2 Year Warranty                |
| MT Components (Key Valve)                                | 5 Year Warranty              | 2 Year Warranty                |
| Refractory Gas Log Sets                                  | 5 Year Warranty              | 2 Year Warranty                |
| Skytech Manufactured Optional Controls                   | 2 Year Warranty              | 1 Year Warranty                |

**OUTDOOR FIREPLACE | KALEA BAY**

| <b>TYPE OF PRODUCT</b>                                | <b>CONSUMER APPLICATIONS</b> | <b>COMMERCIAL APPLICATIONS</b> |
|-------------------------------------------------------|------------------------------|--------------------------------|
| Construction and Manufacturer Defects                 | Lifetime Warranty            | Lifetime Warranty              |
| Stainless Steel Components                            | Lifetime Warranty            | Lifetime Warranty              |
| Gas Valve, pilot Assembly, Power Supply, and Controls | 5 Year Warranty              | 2 Year Warranty                |
| Skytech Manufactured Optional Controls                | 5 Year Warranty              | 2 Year Warranty                |

**SANCTUARY SERIES - GFRC FIRE FEATURES**

| <b>TYPE OF PRODUCT</b>                                                                                                                                                                                                                                                                                           | <b>CONSUMER APPLICATIONS</b> | <b>COMMERCIAL APPLICATIONS</b> |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|--------------------------------|
| GFRC Structure<br><small>* The warranty covers manufacturing defects or structural failure. Small stress cracks and surface crazing are a natural occurrence in GFRC products and are not covered within this warranty. Discoloration over time is a natural process and is not covered by this warranty</small> | * 3 Year Warranty            | * 3 Year Warranty              |
| Burner System<br><small>** Please refer to your burner system warranty for more information about your warranty.</small>                                                                                                                                                                                         | ** Refer to Burner System    | ** Refer to Burner System      |

**ACCESSORIES**

| <b>TYPE OF PRODUCT</b>                                    | <b>CONSUMER APPLICATIONS</b> | <b>COMMERCIAL APPLICATIONS</b> |
|-----------------------------------------------------------|------------------------------|--------------------------------|
| Construction and Manufacturer Defects                     | Lifetime Warranty            | Lifetime Warranty              |
| Stainless Steel Components (Lids, Stainless Steel Covers) | Lifetime Warranty            | Lifetime Warranty              |
| ESTOP1-0H, Windshields, Hoses & Regulators                | 1 Year Warranty              | 1 Year Warranty                |

**For additional details, please refer to the products installation manual**

The end-user must provide a bill of sale, canceled check, or payment record to verify the purchase date and to establish the warranty period. This Limited Warranty shall be valid and limited to the original purchaser only.

**WARNING:** Any modification to the product will void the warranty.

This Limited Warranty shall be limited to the repair and/or replacement of parts that have been proven to be defective under normal use and service. All warranty claims must be made by the Distributor/Dealer account on behalf of the end-user. You may contact Technical Support at 800-966-8126.

Our Technical Service Department must confirm all approved defects. If a defect is confirmed and we approve the claim, we will replace such parts without charge. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

The manufacturer may request defective products returned with an RMA (Return Merchandise Authorization) issued by Firegear Outdoors for specific products, which is considered to be the nature of the defect and or warranty claim. Product to be returned should; be packed so as not to incur damages during transportation. Firegear Outdoors is not responsible for damages on returned items. RMA is valid for thirty (30) days from the date issued. The RMA must be clearly marked on the outside of the package.

Please check with your local building code department or governing agency for proper approvals before purchasing. Firegear Outdoors is not responsible for any violation of local codes.

Travel, diagnostic cost, service labor to repair the defect on warranty parts to and from the factory will be the responsibility of the owner. We will not be responsible for labor charges and/or damage incurred in installation, repair, and replacement. Firegear Outdoors is not responsible for Issues related to gas or electrical installation.

The Limited Warranty is voided if not assembled, installed, and operated as intended. This Limited Warranty does not cover any defects due to accident, abuse, misuse, alteration, misapplication, vandalism, improper installation or improper maintenance or service, removal from the original location, or re-installation into another location, or failure to perform normal and routine maintenance.

Damage due to severe weather conditions such as hail, hurricanes, earthquakes, tornadoes, discoloration due to overheating, exposure to chemicals (including chlorine and salt), either directly or in the atmosphere, or very high humidity, is not covered by this Limited Warranty. Coastal, humid and/or salt environments are subject to manufacturer review. All out-of-box claims must be made within 30 days of purchase and must be made prior to installation. Any product installed damaged will be considered damaged during installation and not covered under warranty.

There are no other express warranties except as set forth herein. For consumer applications, any applicable implied warranties of merchantability and fitness are limited in duration to the period of coverage of this Limited Warranty. Some states do not allow limitation on how long an implied warranty lasts, so this limitation may not apply to you.

For Commercial Applications, the liability of Firegear Outdoors is limited to the express terms of this warranty. We expressly disclaim any and all implied warranties, including any warranties of fitness for a particular purpose or merchantability.

We are not liable for any special, indirect or consequential damages. Our maximum liability is limited to the purchase price of the purchased units. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you.

We do not authorize any person or company to assume for it any other obligation or liability in connection with the sale, installation, use, removal, return, or replacement of its equipment, and or such representation are binding.



Firegear Outdoors  
1600 Riverfork Dr. East  
Huntington, IN 46750

[www.firegearoutdoors.com](http://www.firegearoutdoors.com)







Having problems getting the fire pit to operate? Don't leave the job site! We want to help! Call 260-355-5577 for Technical Support between the hours of 8:30AM to 4:30PM  
**BEFORE YOU CALL WE WILL NEED THIS INFORMATION**

1. Model Number: \_\_\_\_\_
2. Serial Number: \_\_\_\_\_
3. How long is the gas line run? Nat Gas \_\_\_\_\_ LP Gas \_\_\_\_\_
4. What size is gas line? \_\_\_\_\_
5. Inlet Gas Pressure: \_\_\_\_\_ WC  
Manifold Gas Pressure: \_\_\_\_\_ WC
6. What type of media are you using? \_\_\_\_\_
7. Review the troubleshooting section in the installation manual.
8. What are the symptoms? Please be prepared to explain.
9. Be prepared to send photos to us when on the phone.
10. Found missing or damaged parts? Let us know ASAP or send photos.

